

SECTION 6

6.38 CORPORATION STOPS:

Corporation stops provide the connection for the service line to the main. By utilizing a corporation stop, a service can be connected to the main without taking the main out of service. Corporation stops are also used in air and vacuum valve and large butterfly valve installations as shown in Sheets I6 through I8 of the Standard Drawings. Corporation stops are made in standard sizes 3/4, 1 inch, 1-1/4 inch, 1-1/2 inch, and 2 inch. See Chapter 3, MS-21 and Sheets 46 and 48 of the Standard Drawings for further information.